

X
X
X
X
X
X
X
X
X
X
X
X

OVEN MITTS & POT HOLDERS



FUSIONS
by AGF

FREE PATTERN


XXXXXXXXXXXXXXXXXXXX

Emerald

OVEN MITTS & POT HOLDERS

DESIGNED BY AGFstudio

Vert FUSION



FUS-VR-2305
TRÉS STREAKED VERT
by Bari J.



FUS-VR-2306
BRIEF MEMENTOS VERT
by Pat Bravo



FUS-VR-2308
VENTURE VERT
by Sharon Holland

ADDITIONAL BLENDERS FOR THIS PROJECT



PE-419
LIGHT GREY





OVEN MITTS & POT HOLDERS

FINISHED SIZE | 11½" x 6½" - 7" x 7"

FABRIC REQUIREMENTS

Fabric **A** FUS-VR-2305 FQ.

Fabric **B** FUS-VR-2306 ¼ yd.

Fabric **C** FUS-VR-2308 ¼ yd.

Fabric **D** PE-432 ⅝ yd.

BACKING FABRIC

PE-432 (Included)

BINDING FABRIC

Fabric **D** PE-432 (Included)

CUTTING DIRECTIONS

¼" seam allowances are included.
WOF means width of fabric.

- One (1) 18" x 13" rectangle from fabric **A**.
- Two (2) 7" squares from fabric **B**.
- Two (2) 7" squares from fabric **C**.
- One (1) 18" x 13" rectangle from fabric **D**.
- Three (3) 5½" x 1¼" strips from fabric **D**.
- One (1) 14" x 2 ½" strip from fabric **D**.

CONSTRUCTION

Sew all rights sides together with ¼" seam allowance.

- Start by placing one (1) 18" x 13" rectangle from fabric **D**, batting on top and one (1) 18" x 12" rectangle from fabric **A**.
- Quilt all those three layers together.




DIAGRAM 1

- Place template 1 and 2 on top of the quilted piece and cut following the outline of each template.




DIAGRAM 2

- Place both templates facing right sides together and sew from one bottom corner through the opposite bottom corner.
- Turn it inside out.




DIAGRAM 3

To make a hanging loop :

1. Take one (1) $5\frac{1}{2}$ " x $1\frac{1}{4}$ " strip from fabric **D**.
2. Fold it in half lengthwise and sew lengthwise with $\frac{1}{4}$ " seam allowance.
3. Turn the piece right side out.
4. Press flat along the seam line. Make a total of three (3) hanging loops.




DIAGRAM 4

1. Fold (1) hanging loop from fabric **D**, pin it on the bottom side of the oven mitt and stitch it to the bottom edge to secure it.




DIAGRAM 5

- To make the binding for the wrist, take one (1) 14 " x $2\frac{1}{2}$ " strip from fabric **D** and fold in half lengthwise, iron flat.
- Sew with $\frac{1}{4}$ " seam , start from about $1\frac{1}{2}$ " from the side seam and finish off about the same length from the other binder end.
- Fold the binding over to the inside of the oven mitt, stitch the folded edge along the stitching line.




DIAGRAM 6

- Find Oven Mitt's template at the end of the document.

Pot Holders

- Place one (1) 7" square from fabric **B**, batting on top and another 7" square from fabric **C**.
- Quilt as you prefer and trim the excess batting.




DIAGRAM 7

- Take another 5½" x 1¼" hanging loop from fabric **D** sewn before in diagram 4 into half, pin it on one side and stitch it to secure it.




DIAGRAM 8

- Place binding all around the 7" square. Find binding instruction on the next page.




DIAGRAM 9

BINDING

Sew rights sides together.

- Cut enough strips $1\frac{1}{2}$ " wide by the width of the fabric **H** to make a final strip 100" long. Start sewing the binding strip in the middle of one of the sides of the quilt, placing the strip right side down and leaving an approximated 5" tail. Sew with $\frac{1}{4}$ " seam allowance (using straight stitch), aligning the strip's raw edge with the quilt top's raw edge.
- Stop stitching $\frac{1}{4}$ " before the edge of the quilt (DIAGRAM B1). Clip the threads. Remove the quilt from under the machine presser foot. Fold the strip in a motion of 45° and upward, pressing with your fingers (DIAGRAM B2). Hold this fold with your finger, bring the strip down in line with the next edge, making a horizontal fold that aligns with the top edge of the quilt (DIAGRAM B3). Start sewing at $\frac{1}{4}$ " of the border, stitching all the layers. Do the same in the four corners of the quilt.
- Stop stitching before you reach the last 5 or 6 inches. Cut the threads and remove the quilt from under the machine presser foot. Lay the loose ends of the binding flat along the quilt edge, folding the ends back on themselves where they meet. Press them together to form a crease. Using this crease as the stitching line, sew the two open ends of the binding with right sides together (you can help yourself marking with a pencil if the crease is difficult to see).
- Trim seam to $\frac{1}{4}$ " and press open. Complete the sewing. Turn binding to back of the quilt, turn raw edge inside and stitch by hand using blind stitch.

DIAGRAM B1



Stop stitching here

DIAGRAM B2





DIAGRAM B3



*Congratulations
& enjoy*



artgalleryfabrics.com

NOTE: While all possible care has been taken to ensure the accuracy of this pattern, We are not responsible for printing errors or the way in which individual work varies.

Please read instructions carefully before starting the construction of this quilt. If desired, wash and iron your fabrics before starting to cut.

© 2021 Courtesy of Art Gallery Quilts LLC. All Rights Reserved.

